# CURTAINS HANGING GUIDE
## WAVE (S-STYLE)

SHADE IN STYLE
BESPOKE WINDOW DRESSINGS

YOU SHOULD HAVE

Curtain Track


Brackets (For Top Fix)

Brackets (For Face Fix)

Track Joiner

## TOOLS REQUIRED

Screw driver   Drill


Tape measure   Pencil

THE INSTALLATION OF THIS PRODUCT SHOULD BE CONDUCTED BY SOMEONE COMPETENT IN DIY.

STEP 1

BRACKET POSITION

Place curtain track in fitting position, space the brackets evenly.

100mm
(4")
A bracket should sit at either side of the rail, 100mm (4") away from the end.
100mm
(4")

Remaining brackets should be equally distributed along the width.


STEP 2

INSTALLING BRACKETS

Face Fixing

Position bracket against the surface and mark out the holes in the top of the bracket. Use rawl plugs if fitting to the wall.


Top Fixing

Position bracket against the surface and mark out the holes in the back of the bracket. Use rawl plugs if fitting to the ceiling.

Attach the brackets onto curtain track. To do that, rest the front lip of the headrail against the front hook of the bracket. Then twist the back of the rail upwards until it snaps into place.

STEP 3

HANGING YOUR CURTAINS

To hang your Wave (S-fold) curtain, use the hooks on the back of the curtain
to loop through the curtain runners.
To achieve the wave effect with S-fold curtains, make sure the waves
are of even depth in front and behind the track.
If some waves look 'shallow' then gently push that fold back so it creates
a deeper wave at the rear.

Tip

Start the hanging process from the curtain stacking side, with the edge of the curtain pointing towards the window

STEP 4

DRESSING YOUR CURTAINS

Now it's time to 'teach' the pleats to sit in the correct place.
You'll need to grab your masking tape or just a piece of foil of about 1m in length.
With your curtains stacked against the end of the track, gather them while
checking the pleats are still sitting in the correct wave.
Then, loosely tie the tape or foil around the gathered curtains and leave
in place for 2-3 days. This will 'teach' the fabric how you want it to sit.

Tip

New curtains sometimes have visible fold lined or they are cressed from the packaging. These will drop once the curtain is hung and the fabric lustre will return. **If you have access to iron steamer, you can try lightly steaming the curtains fabric on low setting to encourage those creases to drop out faster.**